



Thank You!

You have successfully downloaded your document from Workbenchmagazine.com. Below are some tips for Trouble-Free Printing

- 1)** Clear printer memory. If you are unable to print this document, turn off your printer for at least 15 seconds and try again.

- 2)** Print two or three pages at a time. If clearing the printer memory didn't help, try printing only two or three pages at one time, rather than sending the entire file

- 3)** If a document is required to be at an accurate scale set the page scaling option to "none" in your printer settings.

- 4)** Get advanced printer help. Visit Adobe Support for instructions in troubleshooting common printer problems.

<http://www.adobe.com/support/techdocs/316508.html>

MATERIALS LIST



CASE

- A (4) Legs (oak) $1\frac{1}{16}'' \times 2\frac{3}{8}'' \times 21\frac{1}{4}''$
- B (1) Upper Front Rail (oak) $\frac{3}{4}'' \times 3\frac{5}{8}'' \times 34\frac{3}{4}''$
- C (2) Drawer Rails (oak) $\frac{3}{4}'' \times 1\frac{1}{4}'' \times 34\frac{3}{4}''$
- D (2) Upper Side Rails (oak) $\frac{3}{4}'' \times 3\frac{5}{8}'' \times 16\frac{7}{8}''$
- E (1) Upper Back Rail (oak) $\frac{3}{4}'' \times 3\frac{5}{8}'' \times 34\frac{3}{4}''$
- F (2) Lower Side Rails (oak) $\frac{3}{4}'' \times 7'' \times 16\frac{7}{8}''$
- G (1) Lower Back Rail (oak) $\frac{3}{4}'' \times 7'' \times 34\frac{3}{4}''$
- H (1) Front Panel (plywood) $\frac{1}{2}'' \times 8\frac{1}{8}'' \times 34\frac{3}{4}''$
- I (2) Side Panels (plywood) $\frac{1}{2}'' \times 6\frac{7}{8}'' \times 16\frac{7}{8}''$
- J (1) Back Panel (plywood) $\frac{1}{2}'' \times 6\frac{7}{8}'' \times 34\frac{3}{4}''$
- K (1) Filler Strips (oak) $\frac{1}{4}'' \times \frac{9}{32}'' \times 30''$ rgh.
- L (1) Drawer Panel (plywood) $\frac{3}{4}'' \times 16\frac{1}{4}'' \times 35''$
- M (2) Drawer Guides (oak) $\frac{1}{4}'' \times 1'' \times 16\frac{3}{8}''$
- N (1) Cleats (oak) $\frac{1}{2}'' \times 1\frac{1}{2}'' \times 18$ lin. ft.
- O (1) Chest Bottom (plywood) $\frac{3}{4}'' \times 16\frac{1}{4}'' \times 35''$

CHEST LID

- P (1) Top (plywood) $\frac{3}{4}'' \times 20\frac{1}{8}'' \times 39''$
- Q (2) Edgebanding (oak) $\frac{1}{8}'' \times \frac{3}{4}'' \times 39''$
- R (2) Breadboard Ends (oak) $\frac{3}{4}'' \times 2\frac{1}{2}'' \times 20\frac{3}{8}''$
- S (6) Pegs (oak) $\frac{1}{4}'' \times \frac{3}{4}''$ dowels
- T (1) Support Strip (oak) $\frac{5}{16}'' \times 1'' \times 34\frac{1}{4}''$

DRAWER


- U (1) Drawer Front (oak) $\frac{3}{4}'' \times 4\frac{3}{8}'' \times 34\frac{1}{8}''$
- V (1) Drawer Back (oak) $\frac{1}{2}'' \times 4\frac{3}{8}'' \times 34\frac{1}{8}''$
- W (2) Drawer Sides (oak) $\frac{1}{2}'' \times 4\frac{3}{8}'' \times 15\frac{3}{4}''$
- X (1) Drawer Bottom (plywood) $\frac{1}{4}'' \times 15\frac{3}{4}'' \times 33\frac{3}{8}''$
- Y (1) Drawer Stops (oak) $\frac{3}{4}'' \times 1'' \times 4\frac{1}{4}''$
- Z (10) Cedar Strips $\frac{1}{8}'' \times 3\frac{3}{4}'' \times 16\frac{1}{2}''$

HARDWARE

- (28) #8 x $1\frac{1}{4}''$ Fh Woodscrews
- (28) #8 x 2" Fh Woodscrews
- (12) #6 x $\frac{3}{4}''$ Fh Woodscrews
- (2) $\frac{3}{4}''$ x $2\frac{1}{2}''$ Butt Hinges
- (2) $1\frac{3}{4}''$ x $3\frac{3}{8}''$ Drawer Pulls
- (1) $15\frac{1}{2}''$ -long Black Chain
- (2) UHMW Drawer Bumpers
- (2) $\frac{1}{2}''$ x 16" UHMW Drawer Glide Strips


*NOTE: Some pieces will need to be laminated or planed to get finished size/thickness.

CUTTING DIAGRAM




$\frac{1}{4}'' \times 48'' \times 48''$ Plywood (Qty: 1)


$\frac{1}{4}'' \times 24'' \times 48''$ Plywood (Qty: 1)




$\frac{3}{4}$ " x 48" x 48" Plywood (Qty: 1)



$\frac{3}{4}$ " x 24" x 48" Plywood (Qty: 1)



3/4" x 7 1/2" x 96" (Qty: 1)



3/4" x 7 1/2" x 72" (Qty: 2)

(Plane this board to 1/2" thickness)




1 1/16" x 5 1/2" x 48" (Qty: 1)

(Plane piece to 5/16" thickness)



3/4" x 5 1/2" x 48" (Qty: 1)



3/4" x 7 1/2" x 72" (Qty: 1)



3/4" x 7 1/2" x 48" (Qty: 1)